




TEX:ENERGY[®]
OFF-GRID POWER




TEX-FLEX 10

QUICK
START
GUIDE


START CHARGING YOUR DEVICES:




1 Connect your device to the controller via the appropriate port or using the 8.4V and 12V DC cable and tips.



2 LED's indicate voltage output, charge and charging status. Press battery status button to check charge when not attached to a device.



3 Match up stacking connectors when using multiple Tex-Flex 10s – which will double, triple or quadruple your available capacity.



4 Recharge using the USB to Micro USB recharging cable.

Would you like to know more about Texenergy?

If so, please go to www.texenergy.com where you will be able to find information about our off-grid products, what we do, news, frequently asked questions, contact details and more.

For customer support, email us at support@texenergy.com

Find more Texenergy on

